



Contents



Sweet counter body



2x side trays



Scale base



Scale display



Scale dish



scale dish cradle




2x sweet jars




Scoop



Assorted bag of sweets



lollies




Toy Coins & Toy Bank notes
Sticker Sheet

Cleaning

Wash product thoroughly before use and after use;
Do not immerse product in water or use abrasive cleaners.
Clean using a soft damp cloth and warm water.
Do not place this product in a dishwasher.

How does it work?



WARNING

Unsuitable for children under 36 months due to small components that may prove a choking hazard.
Accessories must be washed thoroughly before use and after use.
USE UNDER DIRECT ADULT SUPERVISION.

